



NOTE:
AT THE HEAD FLASHING ALL CLADDINGS
NEED TO HAVE A SAW CUT AT THE
CORRECT LOCATION TO ALLOW THE
CLADDING TO BE FITTED ONTO THE
FLASHING. THE SAW CUT ALLOWS THE
CLADDING TO BE FITTED AS CLOSE TO
THE TRIM OPENING AS POSSIBLE GIVING
MAXIMUM COVER BEHIND THE FACING.

